

Instructions

Educational PV-System

Assembly and operating instructions

Third edition, August 2025

Editor: Robert Mog

Proofreading: Matthias Schmuderer

Design / Layout: Carina Lützenburger, Robert Mog, Marina Unger, Nele Willenbrink

3D visualisations: Janus Wagner

Translation: Victor Batschkus, Robert Mog

© Solar Bildung, 2025 www.solarbildung.org Solar for Schools Bildung gGmbH Steinstr. 39, Rgb. rechts D-81667 Munich

contact@solarbildung.org

Legal notice:

All contents of this publication, including text, images and graphics, are protected by copyright and may not be reproduced or distributed (except in the classroom) without the written permission of the publisher. This publication is for educational purposes only and the publisher does not guarantee its complete accuracy.










Educational PV-System


Installation & operating instructions


Contents	
01 Components	4
02 Assembly instructions for base	5
03 Assembly instructions for stand	7
04 Assembly instructions for table	10
05 Assembling the components	13
06 Assembling the bracket	14
07 Assembling the solar panel	16
08 Electrical box	18
09 Initial setup	19


01 Components




02 Assembly instruction for base


















03 Assembly instruction for stand

List of components for	stand	
	Aluminium profile long (114cm)	1x
	Aluminium profile short (100 cm)	2x
	beveled aluminium profile with holes (100 cm)	Зх
	135° Brackets	6x
	90° Brackets	2x
	Hammer head screw M8 x 20	16x
	Collar nut M8	16x

Tools
2 x
Ring
wrenches 13
0 0








Carry heavy components together to prevent injuries.


Stand




04 Assembly instruction for table

List of components for	table	
	Aluminium profile long (176,5 cm)	2x
	Aluminium profile short (106 cm)	3x
	Pivot joint	4x
	90° Bracket	8x
	Hammerhead nut M8	8x
	Hexagon socket head cap screw M8 x 15	8x
	Hammer head screw M8 x 20	16x
	Collar nut M8	16x


Tools
2 x
Ring
wrenches 13
2 x
Allen keys








Carry heavy components together to prevent injuries..



05 Assembling the components

Stand + Base






Table + stand/base

06 Assembling the bracket

List of components for bracket		
	Aluminium profile with holes	2x
	Hexagon head screw M8 x 80	4x
	Washer	4x
	Collar nut M8	4x



Carry heavy components together to prevent injuries.



Two people hold the table at a slight angle while two others attach the brackets to the stand.




When attaching the Aluminum to the table, make sure that it can still be rotated and only screw it tight after it has been attached to the stand.



In the following steps, we will align and secure the table. Make sure that the table is tilted toward the sun and use the corresponding holes in the base for this purpose.

First attach the bracket to the table



07 Assembling the solar panel


List of components for solar	panel	
	Solar panel	1x
	Mounting bracket	4x
	Hammer head screw M8	8x
	Collar nut M8	8x




Carry heavy components together to prevent injuries.



When attaching the PV module, make sure that the cables do not get caught on the metal





Educational PV-System – Installation & operating instructions

08 Electrical box



Carry the electrical box together to prevent injuries.

Electrical box




The electrical box should be positioned as centrally as possible between the PV systems. Discuss with your class and your teacher: Which circuit is best for you and why? What are the advantages and disadvantages of series and parallel circuits? You will find the circuit diagrams for both variants on the following pages.

09 Initial setup

Series connection



When installing the electronic components, check for damage on the cable and ensure proper use to avoid injury from electric shock.




Connect the cables from the electrical box to the PV modules in series as shown to enable a circuit. The solar system is now ready for operation. It offers a maximum output of approx. 350 watts. You can now operate several devices, such as one or more electronic instruments, chargers, or a popcorn machine, via a multiple socket.

Parallel connection



When installing the electronic components, check the cable for damage and ensure proper use to avoid injury from electric shock.



Connect the cables from the electrical box to the PV modules in parallel as shown to enable a circuit. The solar system is now ready for operation. It offers a maximum output of approx. 350 watts. You can now use a multiple socket to operate several devices, such as one or more electronic instruments, chargers, or even a popcorn machine.